

**BaByliss** PRO  
STYLIST TOOLS

TITANIUM  
EXPRESSION



— 13mm CURLING TONG —

## TITANIUM EXPRESSION

BaByliss PRO has been at the forefront of hair styling innovation and inspiration for over 50 years. We produce innovative, professional products engineered with demanding session and salon performance in mind.

With our Titanium Expression range, you can create any look from session to salon. Our stylers feature Titanium Ceratherm™ technology; a combination of premium titanium with a fast-action ceramic heating system to give consistent, even heat that you can rely on for a perfect finish.

TITANIUM  
CERATHERM  
SYSTEM

Premium titanium with a fast-action ceramic heating system delivering constant, regulated temperature and instant heat transfer for fast, long-lasting results.



## SAFETY CAUTIONS

- This appliance should only be used as described within this instruction booklet. Please retain for reference.

### **IMPORTANT CHILD SAFETY**

**WARNING!** Polythene bags over product or package may be dangerous. To avoid danger of suffocation, keep this wrapper away from babies and children. This bag is not a toy.

### **WARNING! THIS APPLIANCE GETS HOT!**

- **ALWAYS** keep out of reach of children (during and after use and whilst cooling).
- This appliance should not be used, cleaned or maintained by children.
- Always take extra care if used on children or near children.
- Do not use on very young children.

### **IMPORTANT SAFETY**

- Do not use this appliance in the bathroom.
- **WARNING!** Do not use this appliance near water contained in basins, bathtubs or other vessels.
- Do not immerse the appliance in water or other liquids.
- Always inspect the appliance before use for noticeable signs of damage. Do not use if damaged, or if the appliance has been dropped. In the event of damage, discontinue use immediately and contact the Conair Customer Care Line (refer to 'UK After Sales Service' section for further information).
- Do not use the appliance if the lead is damaged. In the event of lead damage, discontinue use immediately. If the lead is damaged it must be replaced by the manufacturer. Return



the appliance to the Conair Service Centre (refer to 'UK After Sales Service' section for further information). No repair must be attempted by the consumer.

- Do not leave the appliance unattended when switched on or plugged in.
- During use do not place the appliance on any heat sensitive surface, even when using the heat mat provided.
- Take care to avoid the hot surface of the appliance coming into direct contact with the skin, in particular the eyes, ears, face and neck.
- In the event of the appliance left switched on, the appliance will automatically shut off after 72 minutes. If you wish to continue using the appliance after this time, simply press the 'I/O' button to turn the power on.
- This appliance should not be used by adults whose reduced physical, sensory or mental capabilities, or whose lack of experience and knowledge, might cause a hazard, unless they have been correctly instructed to understand the safe use and hazards involved and are adequately supervised.
- After use, do not coil the lead around the appliance as this may cause damage. Instead, coil loosely by the side of the appliance and allow appliance to cool before storing away.
- This product complies fully with all appropriate EU and UK Legislation and the Standards relevant to this type and class of appliance. We are an ISO9001:2015 certified company that continually evaluates our Quality Management System performance. If you have any queries regarding product safety and compliance, please contact the Conair Customer Care Line. (Refer to 'UK After Sales Service' section for further information).

## 13MM CURLING TONG

Create smooth, tight curls with the 13mm Curling Tong featuring a slim titanium-ceramic barrel and up to 210°C high heat. The advanced heating system delivers precision-regulated temperatures and instant heat transfer for fast, long-lasting results.

### FEATURES

- 13mm slim barrel with superior titanium-ceramic finish
- Advanced heating system delivers precision-regulated temperature control
- Ultra-fast heat up and instant heat recovery
- High heat performance up to 210°C
- 11 digital temperature settings for enhanced heat protection on all hair types
- Stay cool safety tip
- Auto shut-off for added safety
- Salon length 2.7m swivel cord for ease of use
- Heat mat with storage compartment for convenience and safety

## HEAT SETTINGS

There are 11 temperature settings to select from (160°C-210°C) for enhanced heat protection on all hair types. If you have delicate, fine or coloured hair, use the lower heat settings. For thicker hair, use the higher heat settings. It is suggested to always complete a test on initial use to ensure the correct temperature is used on the hair type. Start on the lowest setting and increase the temperature until desired result is achieved.

Below is a guide of the temperature settings.

Hair Type Description	Very Fine, Fragile Hair	Regularly Coloured or Highlighted Hair	Fine, Easy to Curl Hair	Normal Textured Hair	Naturally Curly or Wavy Hair	Thick or Coarse Hair
Recommended Temperature Setting	160°C	170°C	180°C	190°C	200°C	210°C

## HOW TO USE YOUR CURLING TONG

**CAUTION!** Do not place the appliance on any heat sensitive surface whilst in operation. Use the heat mat provided to protect the work surface whilst styling your hair.

- Press and hold the button marked 'I/O' to switch the styler on. The temperature display panel will begin to flash 160°C.
- The styler will automatically adjust to the 160°C temperature setting each time it is switched on and this will be displayed on the LCD screen.

**IMPORTANT:** Within 4 seconds of turning the styler on, the temperature setting will automatically lock. You are able to adjust the temperature setting immediately after switching on the styler, however if the temperature locks, hold down either the '+/-' buttons for 1-2 seconds to change the temperature.

- The temperature increases in 5°C increments for specific temperature control (160°C-210°C).

**NOTE:** Always start with a lower temperature setting and increase gradually if required.

- The temperature on the display will flash while the styler is heating up to the selected temperature. You may still change the temperature setting at this time.
- When the selected temperature has been reached, the temperature display will stop flashing.

**WARNING!** This appliance reaches up to 210°C, please take care to avoid the hot surface of the barrel coming in to direct contact with the skin, in particular the ears, eyes, face and neck.

## STYLING ADVICE

- Section dry hair evenly and comb through before styling.
- Press the lever and place the tong midway up the hair section and spread hair evenly between the lever and the barrel.
- Once hair is in place carefully let go of the lever so the hair is held securely between the lever and the barrel. Gently slide the tong down to the hair ends.

**NOTE:** If using this product on someone else, wrap all the hair section around the barrel before you let go of the lever.

- Wind the hair at a slight angle, so the hair wraps around the barrel in a spiral motion. As you wind the hair around the barrel, ensure the hair is distributed evenly so the entire section is touching the barrel; try not to overlap the hair.
- Hold in place for 5-8 seconds depending on the texture and length of the hair.
- To remove the tong from the hair, press the lever and pull tong away.
- Allow the curl to cool before styling it further.
- Repeat as necessary through the remaining sections. Use the heat protection mat to place your styler on between each section to protect surfaces.
- After use, press and hold the 'I/O' button for 1-2 seconds to switch your styler off and unplug.
- Allow to cool completely before storing away. For extra protection, wrap the styler in the salon heat wrap.

## SALON HEAT WRAP

The tong comes with a salon heat wrap for use during and after styling. During use do not place this appliance on any heat sensitive surface, even when using the wrap provided. After use, switch off and unplug the appliance. Immediately wrap the appliance in the heat wrap provided and allow to fully cool down. Continue to keep it out of the reach of children as it will remain hot for several minutes.

**IMPORTANT:** The black satin material is not heat resistant and the appliance should not be placed on this material whilst hot.

## AUTO SHUT-OFF

This appliance has an automatic shut off feature for added safety. If the appliance is switched on for more than 72 minutes continuously, then it will automatically switch off. If you wish to continue using the appliance after this time, simply press the '1/0' button to turn the power on.

## LOOKING AFTER YOUR CURLING TONG

- In order for your styler to retain its top performance it is important to make sure there is no product build up on the barrel. When the styler is completely cool and unplugged, use a damp cloth over the surface of the barrel to wipe away any styling product.
- Keep the power cord away from the hot barrel at all times.
- Before storing away, always allow the barrel to cool down and place in the heat mat provided for extra protection.
- To prevent cord damage, do not wrap the cord around the styler – always store the cord next to it.

## UK GUARANTEE

The Conair Group Ltd, Unit 3, Waterfront Business Park, Fleet, GU51 3TW

This BaByliss PRO appliance is guaranteed for professional use for 6 months and is only valid within the United Kingdom.

### Exclusions

This guarantee will no longer be valid meaning that The Conair Group Ltd will not be liable to repair or replace your product where:

- 1.) The appliance has been used on a voltage supply other than that which is marked on the product, or advised within this instruction booklet
- 2.) The appliance has been purchased from an unauthorised stockist\*
- 3.) Repairs or alterations have been attempted by unauthorised persons
- 4.) The failure of the appliance is a direct result of misuse
- 5.) The failure is a result of not following the instructions for use

This guarantee does not cover any cosmetic damage due to misuse of the product nor any damage to persons or property that occurs because of product misuse.

\*unauthorised stockists include, but are not limited to online auction sites, private sellers and those selling second hand goods, refurbished products etc.

Please contact the Conair Customer Care Line on 03705 133 191 (09:00 to 17:00 Monday to Friday) or e-mail [ukinfo@conair.com](mailto:ukinfo@conair.com) for further information on authorised stockists.

**It is important to retain your proof of purchase. We recommend attaching your receipt to this page.**

**Even where a refund may be applicable, no refund will be provided without a valid receipt or proof of purchase, we will only be able to offer a repair or replacement service. Please note this does not apply if the product was purchased directly from The Conair Group Ltd.**

Guarantees on replacement products run from the original purchase date or date of delivery, whichever is later, and not from the date of replacement.

**This guarantee is an additional benefit and does not affect your statutory rights as a consumer.** If you have any queries regarding this guarantee please contact the Conair Customer Care Line on 03705 133 191 (09:00 to 17:00 Monday to Friday) or e-mail [ukinfo@conair.com](mailto:ukinfo@conair.com).

## UK AFTER SALES SERVICE

For further advice on using the appliance or should you need to return your product, please contact the Conair Customer Care Line on 03705 133 191 (09:00 to 17:00 Monday to Friday) or e-mail your enquiry to [ukinfo@conair.com](mailto:ukinfo@conair.com).

Return address:


Customer Care Centre  
Conair Logistics  
Unit 4, Revolution Park  
Buckshaw Avenue  
Buckshaw Village  
Chorley  
PR7 7DW

Please enclose your returns number, name and address details, together with a copy of proof of purchase and details of the fault.

**Please note this Instruction Booklet is not the guarantee.**

## SAFE DISPOSAL



The  symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead it should be handed to an appropriate collection point for the recycling of Electrical and Electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about the recycling of this product, please contact your local council office or your household waste disposal service.

## CE DECLARATION OF CONFORMITY

We the undersigned, hereby certify the conformity of the following product:

Type of product	: Curling Iron
Type Number	: F85b
Trademark	: BaByliss / CPL
with following characteristics	: 230V~ 50Hz 30W
Country of origin	: China

Within the essential requirements of the CE Directives:

2014/30/EU	ElectroMagnetic Compatibility Directive
2014/35/EU	Low Voltage Directive
2011/65/EC	RoHS Directive
2009/125/EC	Ecodesign Directives implemented by the Commission Regulations (EC) No. 1275/2008 and (EC) No. 278/2009 (where applicable) amended by 2008/28/EC


In accordance with the following standards:

LVD	EN 60335-1	2012	A11; AC (2014)
	EN 60335-2-23	2003	A1; A11; A2
(including EMF)	EN 62233	2008	
Ecodesign	EN 50564	2011	
EMC	EN 55014-1	2006	A1; A2
	EN 61000-3-2	2014	
	EN 61000-3-3	2013	
	EN 55014-2	1997	A1; A2

CE mark first affixed: July 2017

BABYLISS FACO S.P.R.L. (authorised by BABYLISS S.A.R.L and Conair Group Ltd)  
The Managing Director  
Olivier Smal

Signature:  
Date:

  
28.08.17





